



Set Period Duration and Period

1. Press **SET**
2. Press **TIME**
3. **KEY IN** the duration.
 - 12 min. = 1,2,0,0,0
 - 2 min. = 0,2,0,0,0
4. Press **YES**
NOTE: Press NO if you make a mistake.
5. **KEY IN** the period #




Home Score

1. Press SET
2. Press HOME SCORE
3. KEY IN the new score
4. Press TIME to get back to the Time on the display screen.



Guest Score

5. Press SET
6. Press GUEST SCORE
7. KEY IN the new score
8. Press TIME to get back to the Time on the display screen.



Add


1. Press **SET**
2. Press **HOME PENALTY** or **GUEST PENALTY**
3. **KEY IN** the penalty duration
 - 4 min. major = 0,4,0,0
 - 2 min. minor = 0,2,0,0
4. Press **YES**
5. **KEY IN** the player jersey #.
Example: for #2 key in 0,2.

Remove

6. Press **HOME PENALTY** or **GUEST PENALTY**
Note: If you have two penalties, keep pressing HOME PENALTY or GUEST PENALTY to toggle between penalties until you've chosen the one you want to clear.
7. Press **PENALTY CLEAR**
8. Press **YES**.
Note: Press NO if you make a mistake.

Edit

9. Press **HOME PENALTY** or **GUEST PENALTY** (See Note in Step 6)
10. Press **PENALTY EDIT**
11. Press **YES**
Note: Press NO if you make a mistake.
12. **KEY IN** the penalty duration following Step 3.
Note: Can only edit the time, not the number.



Stop / Start Clock

Using Control Board

1. Start Clock – Press **TIME ON**
2. Stop Clock – Press **TIME OFF**

Using Hand Wand

3. Start / Stop Clock with Switch
- NOTE: Board Buttons will no longer work when hand wand is attached.*

Power & Hand Wand

4. Power Switch
5. Hand Wand Connection

