

Set Period Duration

1. Press SET
2. Press TIME
3. KEY IN the duration.
 - 12 min. = 1,2,0,0
 - 2 min. = 0,2,0,0
4. Press YES


NOTE: Press NO if you make a mistake.

1

2

3

4



5

6

7




Set Period

5. Press SET
6. Press PERIOD
7. KEY IN the period #

Home Score

1. Press **SET**
2. Press **HOME SCORE**
3. **KEY IN** the new score
4. Press **YES**

NOTE: Press NO if you make a mistake.



Guest Score

5. Press **SET**
6. Press **GUEST SCORE**
7. **KEY IN** the new score
8. Press **YES**

NOTE: Press NO if you make a mistake.



Add

1. Press **NEW MINOR** for either **HOME** or **GUEST**
2. **KEY IN** the player jersey #
3. **KEY IN** the penalty duration
 - 4 min. major = 0,4,0,0
 - 2 min. minor = 0,2,0,0



Remove

4. Press **VIEW PENALTY** for either **HOME** or **GUEST**,
Note: If you have two penalties, keep pressing VIEW PENALTY to toggle between penalties until you've chosen the one you want to clear.
5. Press **CLEAR PENALTY**
6. Press **YES**
NOTE: Press NO if you make a mistake.



Edit

7. Press **VIEW PENALTY** for either **HOME** or **GUEST**
Note: If you have two penalties, keep pressing VIEW PENALTY to toggle between penalties until you've chosen the one you want to clear.
8. Press **EDIT PENALTY**
9. **KEY IN** the player jersey #
10. **KEY IN** the penalty duration
 - 4 min. major = 0,4,0,0
 - 2 min. minor = 0,2,0,0



Stop / Start Clock

Using Control Board

1. Start Clock – Press **TIME ON**
2. Stop Clock – Press **TIME OFF**

Using Hand Wand

3. Start / Stop Clock with Switch
- NOTE: Board Buttons will no longer work.*



Power & Hand Wand

4. Power Switch
5. Hand Wand Connection

